



### CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S

- □□□: CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S
- / □□□: Schurter
- □□□□□: SWITCH PUSH SPST-NO 100MA 42V
- □□□: [PDF CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S.pdf](#)
- RoHS □□□: □□□ □□ / RoHS □□□□
- □□□ □□□
- □□□□: DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□  
□□□□□ □□□□□ □□□□□.

□ CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□ □□□□□□

□□□□ □□□	CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S
□□□□	Schurter
□□□□	SWITCH PUSH SPST-NO 100MA 42V
□□□□□□ □□ □□□ / ROHS □□□	□□□ □□ / RoHS □□□□
□□ □□	<a href="#">PDF CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S.pdf</a>
□□□□□□ □□ - □□	60V
□□□□□□ □□□ - □□	42V
□□□□	Capacitive, Illuminated
□□□□□ □□	Wire Leads
□□□□ □□□□	Off-Mom
□□□□□	CPS
□□□□ □□□□□ □□□□	Circular - 22.10mm Dia
□□□□	Bulk
□□□□ □□□ □□□	-40°C ~ 60°C
□□□□□ □□□□	Panel Mount, Front
□□□□□□ □□□□ □□□ (□□□□□□)	1 (Unlimited)
□□□□□□ □□□□	-
□□□□□ □□ □□□ / ROHS □□□	Lead free / RoHS Compliant
□□□□□ □□□	IP67 - Dust Tight, Waterproof
□□□□□ □□□□ (□□□□)	5 ~ 28 VDC
□□□□□ □□□□, □□□	LED, Blue/White
□□ □□□ □□□□	Ceramic Actuator, Finger Guide, O Symbol
□□□□□□□ □□	-
□□□□ □□□□	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
□□□□ □□□	100mA (AC/DC)
□□□ - □□□□□ / □□	Clear (White Filter/Diffuser)
□□□□	SPST-NO
□□□□□□□ □□□□	Round, Button, Flush

□□□□ □□□□□

Schurter CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S	□ CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□	CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□
CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□	CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□	CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□
□ CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□ □□□ □□□□	CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□ □□□□ □□□□	□ CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□ □□□□
CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□□	CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□	Schurter CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S □□□□
Schurter CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S	Schurter □□□□	□ Schurter □□□□
Schurter CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S	Schurter Inc. CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1015-S	

□□□□ □□□□

<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1010-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1018-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1021-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1016-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1017-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1014-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1020-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1011-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1009-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1013-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1012-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS22-NO00A10-SNCCWTWF-AI0BWVAR-W1019-S</b> □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>