



97R06S

□□□□ □□□:
 □□□□ / □□□:
 □□□□ □□□□□
 □□□□ □□□:
 RoHS □□□

 □□□□□ □□□□

97R06S
 Grayhill, Inc.
 SWITCH SLIDE DIP SPST 25MA 24V
 97R06S.pdf
 □□□ / RoHS □□□□□
 □□□ □□□
 DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□ □□□□□ □□□□□.

□ 97R06S □□□□ □□□□□□

| | |
|---------------------------|---|
| □□□□ □□□ | 97R06S |
| □□□□ | Grayhill, Inc. |
| □□□□ | SWITCH SLIDE DIP SPST 25MA 24V |
| □□□□□□ □□ □□□ / ROHS □□□ | □□□□ / RoHS □□□□□□ |
| □□ □□ | 97R06S.pdf |
| □□□□ | Yes |
| □□□□□□ □□□ □□□□ | 24VDC |
| □□□□□□ □□ | Gull Wing |
| □□□□□□ | 97 |
| □□ | 0.050" (1.27mm), Half |
| □□□□ | Tube |
| □□□□ □□□ □□□ | -40°C ~ 85°C |
| □□□□□□□□ □□□ | 6 |
| □□□□□□ □□□□ | Surface Mount |
| □□□□□□ □□□□ □□□□ (□□□□□□) | 1 (Unlimited) |
| □□□□□□ □□□□ | 1,000 Cycles |
| □□□□ | 0.348" (8.85mm) |
| □□□□□□ □□ □□□□ / ROHS □□□ | Contains lead / RoHS non-compliant |
| □□ □□ □□□ | 0.061" (1.55mm) |
| □□ □□□ □□□□ | Tape Seal |
| □□□□□□□□ □□ | - |
| □□□□ □□□□ | Dip Switch SPST 6 Position Surface Mount Slide (Standard) Actuator 25mA 24VDC |
| □□□□ □□□ | 25mA |
| □□□□□□ □□□□ | Copper Alloy |
| □□□□ □□□ | Gold |
| □□□□ | SPST |
| □□□□□□ □□□ | Polyamide (PA), Nylon |
| □□□□□□□□ □□□□ | Slide (Standard) |
| □□□□□□ □□□ | Flush, Recessed |

□□□□ □□□□□

| | | |
|------------------------|-----------------------|-----------------------------|
| Grayhill, Inc. 97R06S | □ 97R06S □□□□ | 97R06S □□□□ |
| 97R06S □□ | 97R06S □□□□ | 97R06S □□□ |
| □ 97R06S □□□□ □□□ □□□□ | 97R06S □□□□ □□□□ □□□□ | □ 97R06S □□□ □□□□ |
| 97R06S □□□□□ | 97R06S □ □□□ | Grayhill, Inc. 97R06S □ □□□ |
| Grayhill, Inc. 97R06S | Grayhill, Inc. □□□□ | □ Grayhill, Inc. □□□□ |
| Grayhill, Inc. 97R06S | Grayhill Inc. 97R06S | |

□□□□ □□□□

| | |
|--|---|
| <p>97R06SR □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> | <p>97R04SR □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> |
| <p>97R06RT □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> | <p>97R06SRT □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> |
| <p>97R06T □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> | <p>97R08S □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> |
| <p>97R04S □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> | <p>97R04ST □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> |
| <p>97R08RT □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> | <p>97R06ST □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> |
| <p>97R04T □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> | <p>97R04SRT □□□□□: Grayhill, Inc. □□□□□: SWITCH SLIDE DIP SPST 25MA 24V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p> |