



BEI Sensors

HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S



- □□□□: HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S
- / □□□□: BEI Sensors
- □□□□□□: ROTARY ENCODER OPTICAL 1024PPR
- □□□□: [PDF](#) HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S.pdf
- RoHS □□□□: □□□□ □□ / RoHS □□□□
- □□□ □□□□
- □□□□: DHL/Fedex/TNT/UPS/EMS



□□□□ □□□□ □□□□ □□□□. □□□□ □□□□ □□□□ □□□□□□.

□ HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□ □□□□□□

□□□□ □□□□	HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S
□□□□	BEI Sensors
□□□□	ROTARY ENCODER OPTICAL 1024PPR
□□□□□□ □□ □□□□ / ROHS □□□□	□□□□ □□□□ / RoHS □□□□□□
□□ □□	PDF HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S.pdf
□□□□ - □□□□□□	5 V ~ 15 V
□□□□□□ □□	Connector
□□□□□□	HS25
□□□□□□□□ □□□□ (□□□□□□ □□□□)	7.5B
□□□□ □□□□□□	1024
□□□□ □□□□	Quadrature with Index (Incremental)
□□□□ □□□□	01072-081 1724-1098
□□□□□□	User Selectable
□□□□□□ □□□□	Chassis Mount, Motors
□□□□□□ □□□□ □□□□ (□□□□□□□□)	1 (Unlimited)
□□□□□□ □□□□ □□□□ □□	4 Weeks
□□□□□□ □□ □□□□ / ROHS □□□□	Lead free / RoHS Compliant
ENCODER □□□□□□	Optical
□□□□	No
□□□□ □□□□	No
□□□□□□□□ □□□□	Hole for Shaft

□□□□ □□□□□□

BEI Sensors HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S	□ HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□	HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□
HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□	HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□	HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□
□ HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□ □□□□ □□□□	HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□ □□□□ □□□□	□ HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□ □□□□
HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□□□	HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□	BEI Sensors HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S □□□□
BEI Sensors HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S	BEI Sensors □□□□	□ BEI Sensors □□□□
BEI Sensors HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S	Sensata Technologies – BEI Sensors HS25F-62-R10-BS-1024-ABZC-15V/V-SCS10-M12-S	

□□□□ □□□□

<p>HS25F-62-R1-BS-1024-ABZC-15V/V-SCS4-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>HS25F-37-R2-SS-360-ABZC-28V/V-SCS24 □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 360PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>HS25F-62-R12-SS-1024-ABZC-15V/V-SCS18-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>HS25F-62-R2-BS-1024-ABZC-28V/V-SM12-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>HS25F-50-R2-SS-1024-ABZC-28V/V-SM12 □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>HS25F-62-R10-BS-1024-ABZC-28V/V-SM12-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>HS25F-62-R1-BS-1024-ABZC-15V/V-SM12-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>HS25F-50-R2-SS-1024-ABC-15V/V-SCS18-M16 □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>HS25F-62-R10-BS-1024-ABZC-15V/V-SM12-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: 2 pcs</p> <p>RFQ</p>	<p>HS25F-62-R10-BS-2048-ABZC-28V/V-SM12-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 2048PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>HS25F-62-R10-BS-1024-ABZC-5V/V-SM12-EX-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: 4 pcs</p> <p>RFQ</p>	<p>HS25F-37-R2-SS-500-ABC-5V/V-SM12-EX □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 500PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>