



CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S

□□□□ □□□□: CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S
 □□□□ / □□□□: Schurter
 □□□□ □□□□□□: SWITCH PUSH SPST-NC 100MA 42V
 □□□□ □□□□: CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S.pdf
 RoHS □□□□ □□□□ □□ / RoHS □□□□
 □□□□ □□□□
 □□□□□□ □□□□□□: DHL/Fedex/TNT/UPS/EMS



□□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□□ □□□□□□ □□□□□□.

CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□ □□□□□□

□□□□ □□□□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S
□□□□	Schurter
□□□□	SWITCH PUSH SPST-NC 100MA 42V
□□□□□□ □□ □□□□ / ROHS □□□□	□□□□ □□□□ / RoHS □□□□
□□ □□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S.pdf
□□□□□□ □□ - □□	60V
□□□□□□ □□□□ - □□	42V
□□□□	Capacitive, Illuminated
□□□□□□ □□	Wire Leads
□□□□ □□□□	On-Mom
□□□□□□	CPS
□□□□ □□□□□□ □□□□	Circular - 16.10mm Dia
□□□□	Bulk
□□□□ □□□□ □□□□	-40°C ~ 60°C
□□□□□□ □□□□	Panel Mount, Front
□□□□□□ □□□□ □□□□ (□□□□□□)	1 (Unlimited)
□□□□□□ □□□□	-
□□□□□□ □□ □□□□ / ROHS □□□□	Lead free / RoHS Compliant
□□□□□□ □□□□	IP67 - Dust Tight, Waterproof
□□□□□□ □□□□ (□□□□□)	5 ~ 28 VDC
□□□□□□ □□□□□□, □□□□	LED, Blue/Green
□□ □□□□ □□□□	R Symbol
□□□□□□□□ □□	-
□□□□ □□□□	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
□□□□ □□□□	100mA (AC/DC)
□□□□ - □□□□□□ / □□	Silver
□□□□	SPST-NC
□□□□□□□□ □□□□	Round, Button, Flush

□□□□ □□□□□□

Schurter CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S	<input type="checkbox"/> CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□
CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□
<input type="checkbox"/> CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□ □□□□ □□□□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□ □□□□ □□□□	<input type="checkbox"/> CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□ □□□□
CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□□□	CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□	Schurter CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S □□□□
Schurter CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S	Schurter □□□□	<input type="checkbox"/> Schurter □□□□
Schurter CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S	Schurter Inc. CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1018-S	

□□□□ □□□□

<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1015-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1021-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1019-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1023-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1013-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1017-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1020-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1016-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1024-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1012-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1014-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCSNCF-RI0BGVAR-W1022-S □□□□□□: Schurter □□□□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>