





Carlo Gavazzi

RM1A60A50


□□□□ □□□:
 □□□□ / □□□:
 □□□□ □□□□□
 □□□□ □□□:
 □ RoHS □□□
 □
 □□□□ □□□□

RM1A60A50
 Carlo Gavazzi
 SSR RELAY SPST-NO 50A 42-660V
 RM1A60A50.pdf
 RoHS □□□□□
 □□□ □□□
 DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□ □□□□□ □□□□□.













□ RM1A60A50 □□□□ □□□□□□

□□□□ □□□	RM1A60A50
□□□□	Carlo Gavazzi
□□□□	SSR RELAY SPST-NO 50A 42-660V
□□□□□□ □□ □□□ / ROHS □□□	RoHS □□□□□
□□ □□	 RM1A60A50.pdf
□□□□ - □□□	42V ~ 660V
□□□□ - □□□□	20 ~ 280VAC, 22 ~ 48VDC
□□□□□ □□	Screw Terminal
□□□□□ □□□□□ □□□	-
□□□□□	RM
ROHS ROHS	RoHS Compliant
□□□□	Bulk
□□□ / □□□	Hockey Puck
□□□□ □□□□	AC, Zero Cross
□□□ □□□	1864-1232
□□□□□ □□□□	Chassis Mount
□□□□□□ □□□□ □□□ (□□□□□□)	Not Applicable
□□□□□ □□□□ □□□□ □□	7 Weeks
□□□□ □□□	50A
□□□□ □□□□	Solid State Relay SPST-NO (1 Form A) Hockey Puck
□□□□	SPST-NO (1 Form A)

□□□□ □□□□□

Carlo Gavazzi RM1A60A50	□ RM1A60A50 □□□□	RM1A60A50 □□□□
RM1A60A50 □□	RM1A60A50 □□□□	RM1A60A50 □□□
□ RM1A60A50 □□□□ □□□ □□□□	RM1A60A50 □□□□ □□□□ □□□□	□ RM1A60A50 □□□ □□□□
RM1A60A50 □□□□□	RM1A60A50 □ □□□	Carlo Gavazzi RM1A60A50 □ □□□
Carlo Gavazzi RM1A60A50	Carlo Gavazzi □□□□	□ Carlo Gavazzi □□□□
Carlo Gavazzi RM1A60A50		

□□□□ □□□□

 <p>RM1A48D75 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 75A 42-530V □□□□ □□□□ □□: 150 pcs</p> <p>RFQ</p>	 <p>RM1C40D25 □□□□□: Carlo Gavazzi □□□□□: SSR PS 400V 25A 4.25-32VDC □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
 <p>RM1E23AA50 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 50A 90-280V □□□□ □□□□ □□: 26 pcs</p> <p>RFQ</p>	 <p>RM1A48A75 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 75A 42-530V □□□□ □□□□ □□: 73 pcs</p> <p>RFQ</p>
 <p>RM1B23D25 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 25A 42-265V □□□□ □□□□ □□: 15 pcs</p> <p>RFQ</p>	 <p>RM1A60D100 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 100A 42-660V □□□□ □□□□ □□: 96 pcs</p> <p>RFQ</p>
 <p>RM1A48D100 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 100A 42-530V □□□□ □□□□ □□: 68 pcs</p> <p>RFQ</p>	 <p>RM1A60A100 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 100A 42-660V □□□□ □□□□ □□: 48 pcs</p> <p>RFQ</p>
 <p>RM1A60D50 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 50A 42-660V □□□□ □□□□ □□: 124 pcs</p> <p>RFQ</p>	 <p>RM1E23AA25 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 25A 90-280V □□□□ □□□□ □□: 40 pcs</p> <p>RFQ</p>
 <p>RM1A48D50 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 50A 42-530V □□□□ □□□□ □□: 113 pcs</p> <p>RFQ</p>	 <p>RM1A48D25 □□□□□: Carlo Gavazzi □□□□□: SSR RELAY SPST-NO 25A 42-530V □□□□ □□□□ □□: 146 pcs</p> <p>RFQ</p>