

Honeywell

Honeywell Sensing and Productivity Solutions

2TL1-6F

- □□□:
- / □□□:
- □□□□□:
- □□□:
- RoHs □□□
-
- □□□□

2TL1-6F
 Honeywell Sensing and Productivity Solutions
 SWITCH TOGGLE DPST-NO 10A 125V
[PDF 2TL1-6F.pdf](#)
 □□□ □□ / RoHS □□□□
 □□□ □□□
 DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□ □□□□□ □□□□□.

□ 2TL1-6F □□□□ □□□□□□

| | |
|--------------------------|--|
| □□□□ □□□ | 2TL1-6F |
| □□□□ | Honeywell Sensing and Productivity Solutions |
| □□□□ | SWITCH TOGGLE DPST-NO 10A 125V |
| □□□□□□ □□ □□□ / ROHS □□□ | □□□ □□ / RoHS □□□□ |
| □□ □□ | PDF 2TL1-6F.pdf |
| □□□□□□ □□□ - □□ | 125V |
| □□□□□ □□ | Screw Terminal |
| □□□□ □□□□ | Off-Mom |
| □□□□□ | TL |
| □□□□ □□□□□ □□□□ | Circular - 12.40mm Dia |
| □□□□ | Bulk |
| □□□ □□□ | 2TL1-6F-ND 2TL16F 480-3449 |
| □□□□ □□□ □□□ | -65°C ~ 71°C |
| □□□□□ □□□□ | Panel Mount |
| □□□□□□ □□□□ □□□ (□□□□□□) | 1 (Unlimited) |
| □□□□□ □□□□ □□□□ □□ | 10 Weeks |
| □□□□□ □□ □□□ / ROHS □□□ | Lead free / RoHS Compliant |
| □□□□□ □□□ | Environment Proof |
| □□□□□ □□□□ (□□□□) | - |
| □□□□□ □□□□, □□□□ | - |
| □□□□ | Non-Illuminated |
| □□ □□□ □□□□ | - |
| □□□□□□□ □□ | - |
| □□□□ □□□□ | Toggle Switch DPST-NO Panel Mount |
| □□□□ □□□ | 10A (AC) |
| □□□□ | DPST-NO |
| □□□ □□ | 15/32-32 |
| □□□□□□□ □□□□ | Locking Lever |
| □□□□□ □□□□ | Nickel Plated |
| □□□□ □□□□ | 26.67mm |

□□□□ □□□□□

| | | |
|--|---|---|
| Honeywell Sensing and Productivity Solutions 2TL1-6F | □ 2TL1-6F □□□□ | 2TL1-6F □□□□ |
| 2TL1-6F □□ | 2TL1-6F □□□□ | 2TL1-6F □□□ |
| □ 2TL1-6F □□□□ □□□ □□□□ | 2TL1-6F □□□□ □□□□ □□□□ | □ 2TL1-6F □□□ □□□□ |
| 2TL1-6F □□□□□ | 2TL1-6F □ □□□ | Honeywell Sensing and Productivity Solutions 2TL1-6F □□□□ |
| Honeywell Sensing and Productivity Solutions 2TL1-6F | Honeywell Sensing and Productivity Solutions □□□□ | □ Honeywell Sensing and Productivity Solutions □□□□ |
| Honeywell Sensing and Productivity Solutions 2TL1-6F | HONEYWELL 2TL1-6F | Honeywell Sensing and Control EMEA 2TL1-6F |
| Honeywell Sensing and Productivity Solutions T&M 2TL1-6F | | |

□□□□ □□□□

| | |
|--|---|
| <p>2TL1-61E □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPST-NO 10A 125V □□□□ □□□□ □□: Out stock RFQ</p> | <p>2TL1-72E □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: Out stock RFQ</p> |
| <p>2TL1-7 □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: 68 pcs RFQ</p> | <p>2TL1-5K □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: 3 pcs RFQ</p> |
| <p>2TL1-5M □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: Out stock RFQ</p> | <p>2TL1-72 □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: Out stock RFQ</p> |
| <p>2TL1-61 □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPST-NO 10A 125V □□□□ □□□□ □□: 1 pcs RFQ</p> | <p>2TL1-70E □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: Out stock RFQ</p> |
| <p>2TL1-7E □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: 3 pcs RFQ</p> | <p>2TL1-70 □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: 13 pcs RFQ</p> |
| <p>2TL1-5L □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPDT 10A 125V □□□□ □□□□ □□: Out stock RFQ</p> | <p>2TL1-6 □□□□□: Honeywell Sensing and Productivity Solutions □□□□□: SWITCH TOGGLE DPST-NO 10A 125V □□□□ □□□□ □□: 24 pcs RFQ</p> |

