



CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S

- □□□: CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S
- / □□□: Schurter
- □□□□□: SWITCH PUSH SPST-NO 100MA 42V
- □□□: CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S.pdf
- RoHS □□□ □□□ □□ / RoHS □□□□
- □□□ □□□
- □□□□ DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□
□□□□□ □□□□□ □□□□□.

□ CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□ □□□□□□

□□□□ □□□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S
□□□□	Schurter
□□□□	SWITCH PUSH SPST-NO 100MA 42V
□□□□□□ □□ □□□ / ROHS □□□	□□□ □□ / RoHS □□□□
□□ □□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S.pdf
□□□□□□ □□ - □□	60V
□□□□□□ □□□ - □□	42V
□□□□	Capacitive, Illuminated
□□□□□ □□	Wire Leads
□□□□ □□□□	Off-Mom
□□□□□	CPS
□□□□ □□□□□ □□□□	Circular - 22.10mm Dia
□□□□	Bulk
□□□□ □□□ □□□	-40°C ~ 60°C
□□□□□ □□□□	Panel Mount, Front
□□□□□□ □□□□ □□□ (□□□□□□)	1 (Unlimited)
□□□□□□ □□□□	-
□□□□□ □□ □□□ / ROHS □□□	Lead free / RoHS Compliant
□□□□□ □□□	IP67 - Dust Tight, Waterproof
□□□□□ □□□□ (□□□□)	5 ~ 28 VDC
□□□□□ □□□□, □□□	LED, Cyan/White
□□ □□□ □□□□	Ceramic Actuator, DOWN Symbol
□□□□□□□ □□	-
□□□□ □□□□	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
□□□□ □□□	100mA (AC/DC)
□□□ - □□□□□ / □□	Clear (White Filter/Diffuser)
□□□□	SPST-NO
□□□□□□□ □□□□	Round, Button, Flush

□□□□ □□□□□

Schurter CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S	□ CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□
CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□
□ CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□ □□□ □□□□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□ □□□□ □□□□	□ CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□ □□□□
CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □□□□□	CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □ □□□	Schurter CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S □ □□□
Schurter CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S	Schurter □□□□	□ Schurter □□□□
Schurter CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S	Schurter Inc. CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1068-S	

□□□□ □□□□

<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1072-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1065-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1067-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1064-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1073-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1069-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1063-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1070-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1062-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1074-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1071-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS22-NO00A10-SNCCWTNF-AI0CWVAR-W1066-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NO 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>