



CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S

□□□□ □□□: CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S
 □□□□ / □□□: Schurter
 □□□□ □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V
 □□□□ □□□: [PDF CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S.pdf](#)
 RoHS □□□ □□□ □□ / RoHS □□□□
 □□□ □□□
 □□□□□ □□□□ DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□ □□□□□ □□□□□.

CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□ □□□□□□□

□□□□ □□□	CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S
□□□□	Schurter
□□□□	SWITCH PUSHBUTTON SPST 100MA 42V
□□□□□□ □□ □□□ / ROHS □□□	□□□ □□ / RoHS □□□□
□□ □□	PDF CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S.pdf
□□□□□□ □□ - □□	60V
□□□□□□ □□□ - □□	42V
□□□□	Capacitive, Illuminated
□□□□□ □□	Wire Leads
□□□□ □□□□	Off-On
□□□□□	CPS
□□□□ □□□□□ □□□□	Circular - 16.10mm Dia
□□□□	Bulk
□□□□ □□□ □□□	-40°C ~ 60°C
□□□□□ □□□□	Panel Mount, Front
□□□□□□ □□□□ □□□ (□□□□□□)	1 (Unlimited)
□□□□□□ □□□□	-
□□□□□ □□ □□□ / ROHS □□□	Lead free / RoHS Compliant
□□□□□ □□□	IP67 - Dust Tight, Waterproof
□□□□□ □□□□ (□□□□)	5 ~ 28 VDC
□□□□□ □□□□, □□□	LED, Magenta/Red
□□ □□□ □□□□	Ceramic Actuator, UP Symbol
□□□□□□□ □□	-
□□□□ □□□□	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
□□□□ □□□	100mA (AC/DC)
□□□ - □□□□□ / □□	Clear (White Filter/Diffuser)
□□□□	SPST
□□□□□□□ □□□□	Round, Button, Flush

□□□□ □□□□□

Schurter CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S	<input type="checkbox"/> CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□	CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□
CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□	CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□	CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□
<input type="checkbox"/> CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□ □□□ □□□□	CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□ □□□□ □□□□	<input type="checkbox"/> CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□ □□□□
CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□□	CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□	Schurter CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S □□□□
Schurter CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S	Schurter □□□□	<input type="checkbox"/> Schurter □□□□
Schurter CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S	Schurter Inc. CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1067-S	

□□□□ □□□□

<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1066-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1063-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1072-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1064-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1062-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1073-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1071-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1070-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1061-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1065-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1068-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AI0MRVAR-W1069-S □□□□□: Schurter □□□□□: SWITCH PUSHBUTTON SPST 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>