



H40A-8X6NB-28V/V-CW-SC

□□□□ □□□□: H40A-8X6NB-28V/V-CW-SC
 □□□□ / □□□□: BEI Sensors
 □□□□ □□□□□□: ROTARY ENCODER OPTICAL 8PPR
 □□□□ □□□□: H40A-8X6NB-28V/V-CW-SC.pdf
 □ RoHS □□□□: □□□□ □□ / RoHS □□□□
 □ □□□ □□□□
 □□□□ □□□□: DHL/Fedex/TNT/UPS/EMS



□□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□ □□□□□ □□□□□□.

□ H40A-8X6NB-28V/V-CW-SC □□□□ □□□□□□

□□□□ □□□□	H40A-8X6NB-28V/V-CW-SC
□□□□	BEI Sensors
□□□□	ROTARY ENCODER OPTICAL 8PPR
□□□□□□ □□ □□□□ / ROHS □□□□	□□□□ □□□□ / RoHS □□□□□□
□□ □□	H40A-8X6NB-28V/V-CW-SC.pdf
□□□□ - □□□□□□	5 V ~ 28 V
□□□□□□ □□	Terminal Block, Straight - Push In
□□□□□□	H40
□□□□□□□□ □□□□ (□□□□□□ □□□□)	-
□□□□ □□□□□□□□	8
□□□□ □□□□	Binary (Absolute), Quadrature with Index (Incremental)
□□□□ □□□□	01018-917
□□□□□□	User Selectable
□□□□□□ □□□□	Chassis Mount
□□□□□□ □□□□ □□□□ (□□□□□□□□)	1 (Unlimited)
□□□□□□ □□□□ □□□□ □□	4 Weeks
□□□□□□ □□ □□□□ / ROHS □□□□	Lead free / RoHS Compliant
ENCODER □□□□□□	Optical
□□□□□	No
□□□□ □□□□	No
□□□□□□□□ □□□□	Shaft

□□□□ □□□□□□

BEI Sensors H40A-8X6NB-28V/V-CW-SC	□ H40A-8X6NB-28V/V-CW-SC □□□□□	H40A-8X6NB-28V/V-CW-SC □□□□□
H40A-8X6NB-28V/V-CW-SC □□	H40A-8X6NB-28V/V-CW-SC □□□□□	H40A-8X6NB-28V/V-CW-SC □□□□
□ H40A-8X6NB-28V/V-CW-SC □□□□ □□□□ □□□□	H40A-8X6NB-28V/V-CW-SC □□□□ □□□□ □□□□	□ H40A-8X6NB-28V/V-CW-SC □□□□ □□□□
H40A-8X6NB-28V/V-CW-SC □□□□□	H40A-8X6NB-28V/V-CW-SC □ □□□	BEI Sensors H40A-8X6NB-28V/V-CW-SC □ □□□
BEI Sensors H40A-8X6NB-28V/V-CW-SC	BEI Sensors □□□□	□ BEI Sensors □□□□
BEI Sensors H40A-8X6NB-28V/V-CW-SC	Sensata Technologies – BEI Sensors H40A-8X6NB-28V/V-CW-SC	

□□□□ □□□□

<p>H40A-1024-ABZC-28V/V-SC-UL-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: 6 pcs</p> <p>RFQ</p>	<p>H40A-CCW-8GC-28V/OC-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 8PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>H40A-512-ABZC-28V/V-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 512PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>H40A-2000-ABZC-28V/V-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 2000PPR □□□□ □□□□ □□: 3 pcs</p> <p>RFQ</p>
<p>H40A-5X8GC-28V/V-CCW-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER ABSOLUTE □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>H40A-1024-ABZC-28V/V-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>H40A-2500-ABC-28V/V-SC-UL □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 2500PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>H40A-50-ABZC-15V/V-SC □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 50PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>H40A-500-ABC-28V/V-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 500PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>H40A-1024-ABZC-28V/V-SC □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 1024PPR □□□□ □□□□ □□: 3 pcs</p> <p>RFQ</p>
<p>H40A-12GC-S3-CW-EM18 □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER ABSOLUTE 4096PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>H40A-500-ABZC-28V/V-SC-S □□□□□□: BEI Sensors □□□□□□: ROTARY ENCODER OPTICAL 500PPR □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>