



CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S

□□□□ □□□: CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S
 □□□□ / □□□: Schurter
 □□□□ □□□□□: SWITCH PUSH SPST-NC 100MA 42V
 □□□□ □□□: CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S.pdf
 □ RoHS □□□ □□□ □□ / RoHS □□□□
 □ □□□ □□□
 □□□□□ □□□□ DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□
 □□□□□ □□□□□ □□□□□.

□ CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□ □□□□□□

□□□□ □□□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S
□□□□	Schurter
□□□□	SWITCH PUSH SPST-NC 100MA 42V
□□□□□□ □□ □□□ / ROHS □□□	□□□ □□ / RoHS □□□□
□□ □□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S.pdf
□□□□□□ □□ - □□	60V
□□□□□□ □□□ - □□	42V
□□□□	Capacitive, Illuminated
□□□□□ □□	Wire Leads
□□□□ □□□□	On-Mom
□□□□□	CPS
□□□□ □□□□□ □□□□	Circular - 16.10mm Dia
□□□□	Bulk
□□□□ □□□ □□□	-40°C ~ 60°C
□□□□□ □□□□	Panel Mount, Front
□□□□□□ □□□□ □□□ (□□□□□□)	1 (Unlimited)
□□□□□□ □□□□	-
□□□□□ □□ □□□ / ROHS □□□	Lead free / RoHS Compliant
□□□□□ □□□	IP67 - Dust Tight, Waterproof
□□□□□ □□□□ (□□□□)	5 ~ 28 VDC
□□□□□ □□□□, □□□	LED, Red/Green/Blue
□□ □□□ □□□□	Ceramic Actuator, Finger Guide, Arrow Symbol
□□□□□□□ □□	-
□□□□ □□□□	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
□□□□ □□□	100mA (AC/DC)
□□□ - □□□□□ / □□	Clear (White Filter/Diffuser)
□□□□	SPST-NC
□□□□□□□ □□□□	Round, Button, Flush

□□□□ □□□□□

Schurter CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S	□ CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□
CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□
□ CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□ □□□ □□□□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□ □□□□ □□□□	□ CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□ □□□□
CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□□	CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□	Schurter CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S □□□□
Schurter CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S	Schurter □□□□	□ Schurter □□□□
Schurter CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S	Schurter Inc. CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1048-S	

□□□□ □□□□

<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1044-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1051-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1049-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1052-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1045-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1043-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1053-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1046-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1047-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1050-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>
<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1042-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>	<p>CPS16-NC00A10-SNCCWTWF-AIRGBVAR-W1054-S □□□□□: Schurter □□□□: SWITCH PUSH SPST-NC 100MA 42V □□□□ □□□□ □□: Out stock</p> <p>RFQ</p>