



### CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S

□□□□ □□□: CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S  
 □□□□ / □□□: Schurter  
 □□□□ □□□□□: SWITCH PUSH SPST-NO 100MA 42V  
 □□□□ □□□: [PDF CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S.pdf](#)  
 □ RoHS □□□: □□□ □□ / RoHS □□□□  
 □: □□□ □□□  
 □□□□□ □□□□: DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□  
 □□□□□ □□□□□ □□□□□.

□ CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□ □□□□□□

|                          |  |
|--------------------------|--|
| □□□□ □□□                 | CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S                              |
| □□□□                     | Schurter   |
| □□□□                     | SWITCH PUSH SPST-NO 100MA 42V  |
| □□□□□□ □□ □□□ / ROHS □□□ | □□□ □□ / RoHS □□□□   |
| □□ □□                    | <a href="#">PDF CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S.pdf</a>      |
| □□□□□□ □□ - □□           | 60V  |
| □□□□□□ □□□ - □□          | 42V  |
| □□□□                     | Capacitive, Illuminated  |
| □□□□□ □□                 | Wire Leads   |
| □□□□ □□□□                | Off-Mom  |
| □□□□□                    | CPS  |
| □□□□ □□□□□ □□□□          | Circular - 22.10mm Dia   |
| □□□□                     | Bulk   |
| □□□□ □□□ □□□             | -40°C ~ 60°C   |
| □□□□□ □□□□               | Panel Mount, Front   |
| □□□□□□ □□□□ □□□ (□□□□□□) | 1 (Unlimited)  |
| □□□□□□ □□□□              | -  |
| □□□□□ □□ □□□ / ROHS □□□  | Lead free / RoHS Compliant   |
| □□□□□ □□□                | IP67 - Dust Tight, Waterproof  |
| □□□□□ □□□□ (□□□□)        | 5 ~ 28 VDC   |
| □□□□□ □□□□, □□□          | LED, Cyan/Red  |
| □□ □□□ □□□□              | Finger Guide, K Symbol   |
| □□□□□□□ □□               | -  |
| □□□□ □□□□                | Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front |
| □□□□ □□□                 | 100mA (AC/DC)  |
| □□□ - □□□□□ / □□         | Silver   |
| □□□□                     | SPST-NO  |
| □□□□□□□ □□□□             | Round, Button, Flush   |

□□□□ □□□□□

|   |  |  |
|---|--|--|
| Schurter CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S        | □ CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□         | CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□           |
| CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□              | CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□           | CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□           |
| □ CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□ □□□ □□□□ | CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□ □□□□ □□□□ | □ CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□ □□□□     |
| CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □□□□□           | CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □ □□□          | Schurter CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S □ □□□ |
| Schurter CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S        | Schurter □□□□  | □ Schurter □□□□  |
| Schurter CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S        | Schurter Inc. CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1011-S  |  |

□□□□ □□□□

|   |   |
|---|---|
| <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1014-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> | <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1012-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> |
| <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1013-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> | <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1007-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> |
| <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1015-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> | <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1005-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> |
| <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1010-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> | <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1017-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> |
| <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1016-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> | <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1006-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> |
| <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1008-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> | <p><b>CPS22-NO00A10-SNCSNCWF-RI0CRVAR-W1009-S</b><br/>                 □□□□□: Schurter<br/>                 □□□□□: SWITCH PUSH SPST-NO 100MA 42V<br/>                 □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p> |