



### CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S

□□□□ □□□: CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S  
 □□□□ / □□□: Schurter  
 □□□□ □□□□□: SWITCH PUSH SPST-NO 100MA 42V  
 □□□□ □□□: CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S.pdf  
 RoHS □□□ □□□ □□ / RoHS □□□□  
 □□□ □□□  
 □□□□□ □□□□ DHL/Fedex/TNT/UPS/EMS



□□□ □□□□ □□□□ □□□□. □□□□  
 □□□□□ □□□□□ □□□□□.

CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□ □□□□□□

□□□□ □□□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S
□□□□	Schurter
□□□□	SWITCH PUSH SPST-NO 100MA 42V
□□□□□□ □□ □□□ / ROHS □□□	□□□ □□ / RoHS □□□□
□□ □□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S.pdf
□□□□□□ □□ - □□	60V
□□□□□□ □□□ - □□	42V
□□□□	Capacitive, Illuminated
□□□□□ □□	Wire Leads
□□□□ □□□□	Off-Mom
□□□□□	CPS
□□□□ □□□□□ □□□□	Circular - 19.10mm Dia
□□□□	Bulk
□□□□ □□□ □□□	-40°C ~ 60°C
□□□□□ □□□□	Panel Mount, Front
□□□□□□ □□□□ □□□ (□□□□□□)	1 (Unlimited)
□□□□□□ □□□□	-
□□□□□ □□ □□□ / ROHS □□□	Lead free / RoHS Compliant
□□□□□ □□□	IP67 - Dust Tight, Waterproof
□□□□□ □□□□ (□□□□)	5 ~ 28 VDC
□□□□□ □□□□, □□□	LED, Red/Green
□□ □□□ □□□□	Ceramic Actuator, Finger Guide, Arrow Symbol
□□□□□□□ □□	-
□□□□ □□□□	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
□□□□ □□□	100mA (AC/DC)
□□□ - □□□□□ / □□	Clear (White Filter/Diffuser)
□□□□	SPST-NO
□□□□□□□ □□□□	Round, Button, Flush

□□□□ □□□□□

Schurter CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S	<input type="checkbox"/> CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□
CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□
<input type="checkbox"/> CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□ □□□ □□□□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□ □□□□ □□□□	<input type="checkbox"/> CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□ □□□□
CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□□	CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□	Schurter CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S □□□□
Schurter CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S	Schurter □□□□	<input type="checkbox"/> Schurter □□□□
Schurter CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S	Schurter Inc. CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1048-S	

□□□□ □□□□

<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1052-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1045-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1044-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1047-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1053-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1051-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1043-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1054-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1046-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1042-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1050-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-NO00A10-SNCCWTWF-AIORGVAR-W1049-S</b>                  □□□□□: Schurter                  □□□□□: SWITCH PUSH SPST-NO 100MA 42V                  □□□□ □□□□ □□: Out stock</p> <p><b>RFQ</b></p>